

APPROVED BY:

 LAF Racing Commission Jānis Ducmanis	 LASF Racing Commission Inga Kačinskiene	 EAL Racing Commission Toomas Lambin
---	--	--

BULLETIN No 1 – Refueling

14.4. During the race refueling drivers must stay in the car. Driver changes, any repair or tire changing works are forbidden during that time, **except cooling of the brakes by two other mechanics that are not involved in refueling**. After refueling mechanics must immediately leave refueling zone. The procedure of refueling starts when the car is fully stopped.

14.11. Only **1 (one)** men powered mechanical pump can be used during the refueling.

14.12. The refueling equipment must be checked and certified by technical scrutineers during each racing event / round.

GOOD LUCK!